


User Settings: EDGE Preferences Settings



Programmed Result of Tool:

Provides users with a dialog interface to define EDGE Preferences and save the settings file as "EDGE_Preferences.txt" to C:/EDGEforREVIT/.

Steps to Perform tool Operation:

This tool will save user defined EDGE Preferences settings as EDGE_Preferences.txt to this folder location, C:/EDGEforREVIT.

- 1) User clicks EDGE Preferences under the User Settings tab.
- 2) User defines the preference settings for each parameter.
- 3) By clicking the Save button, the current settings will be saved to the EDGE_Preferences text file. If the file already exists, the latest settings will overwrite it.

Known Limitations:

- The Current EDGE Preferences Settings won't be applied immediately. Settings saved in the current Revit session will be applied after the user closes out of Revit then reopens Revit.

User Settings: EDGE Preferences Settings

Users can define the folder path for each settings file. If left blank, all files will be saved to the following folder: C:/EDGEforREVIT

Disable specific Tool Panels or Tools by unchecking the corresponding checkbox.

If this box is checked then rebar will be given a control mark based on the rebar settings file (saved in the location defined above) for a specific manufacturer. This manufacturer is based on the manufacturer specified in the Project Information

Current settings will be saved to the EDGE_Preferences text file located in the folder path below: C:/EDGEforREVIT/

