


User Settings: Title Block Populator Settings




Programmed Result of Tool:

This tool will provide users with an interface to map project parameters grouped under the “Structural Framing” and/or “Assemblies” Category to project parameters grouped in the “Sheet” Category.

Steps to Perform Tool Operation:

This tool is intended to help users more efficiently map title block parameters.

- 1) User will run the Title Block Populator Settings tool under the User Settings menu.
- 2) The Mappings that have been grayed out are predefined mappings and cannot be modified.
- 3) Users can select from the drop-down lists to define the parameters to map FROM/TO.
- 4) Users can use the button “Add Mapping” to add new mappings to the list and use the button “Delete Mapping” to delete one or more mappings from the list.
- 5) The “Save” button will save the settings to the folder location specified in the EDGE Preferences. If the folder path doesn’t exist, the file will be saved to the folder C:/EDGEforREVIT. The file is saved with the following naming convention:
<project manufacturer>_TitleBlock_Mapping.xml



Known Limitations:

- Any parameter that you are mapping from must have the same parameter type as the parameter that you are mapping to.